

ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

USER MANUAL

FW 300+



USER MANUAL

This product manual contains important information about the safe installation and use of this projector. Please read and follow these instructions carefully and keep this manual in a safe place for future reference.

Please read the instructions carefully before use!

brighter

ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

1. SAFETY PRECAUTIONS

This fixture is a sophisticated piece of electronic equipment. To guarantee a smooth operation, it is important to follow all instructions and guidelines in this manual. Manufacturer is not responsible for injuries and damages resulting from the misuse of this fixture due to the disregard of the information printed in this manual. Only qualified or certified personnel should perform installation of this fixture and only the original rigging parts included with this fixture should be used for installation. Any modifications to the fixture and the included mounting hardware will void the original manufacturer's warranty and increase the risk of damage personal injury.

- PROTECTION CLASS 1 FIXTURE MUST BE PROPERLY GROUNDED
- THERE ARE NO USER SERVICEABLE PARTS INSIDE THIS UNIT.DO NOT ATTEMPT ANY REPAIRS YOURSELF,AS DOING SO WILL VOID YOUR MANUFACTURER'S WARRANTY. DAMAGES RESULTING FROM MODIFICATIONS TO THIS FIXTURE AND/OR THE DISREGARD OF SAFETY INSTRUCTIONS AND GUIDELINES IN THIS MANUAL VOID THE MANUFACTURER'S WARRANTY AND ARE NOT SUBJECT TO ANY WARRANTY CLAIMS AND/OR REPAIRS
- DO NOT PLUG FIXTURE INTO A DIMMER PACK
- NEVER OPEN THIS FIXTURE WHILE IN USE!
- UNPLUG POWER BEFORE SERVICING FIXTURE
- NEVER TOUCH FIXTURE DURING OPERATION. AS IT MAY BE HOT! KEEP FLAMMABLE MATERIALS AWAY FROM FIXTURE
- NEVER LOOK DIRECTLY INTO THE LIGHT SOURCE
- RETINA INJURY RISK MAY INDUCE BLINDNESS
- SENSITIVE PERSONS MAY SUFFER AN EPILEPTIC SHOCK
- ENSURE THAT ALL CONNECTIONS AND END CAPS ARE PROPERLY SEALED WITH A DIELECTRIC GREASE (AVAILABLE AT MOST ELECTRICAL SUPPLIERS) TO PREVENT WATER CORROSION AND/OR ELECTRICAL SHORT CIRCUIT
- KEEP APPROPRIATE DISTANCE FROM OBJECTS/SURFACES 1 METER (3.3 FEET)
- MAXIMUM TEMP OF EXTERNAL SURFACE 185° F (85°C)
- MINIMUM DISTANCE OF FLAMMABLE MATERIALS FROM THE SURFACE IS 1.6 FEET (0.5 METER)
- DO NOT TOUCH THE FIXTURE HOUSING DURNING OPERATION. TURN OFF THE POWER AND ALLOW APPROXIMATELY
 15 MINUTES FOR THE FIXTURE TO COOL DOWN BEFORE SERVICING
- DO NOT SHAKE FIXTURE. AND AVOID BRUTE FORCE WHEN INSTALLING OPERATING
- DO NOT operate fixture if the power cord is frayed, crimped, damaged or if any of the power cord connectors are damaged and do not insert into the fixture securely with ease
- NEVER force a power cord connector into the fixture. If the power cord or any of its connectors are damaged,
 replace it immediately with a new one of the same power rating
- DO NOT block any air ventilation slots
- All fan and air inlets must remain clean and never blocked
- Allow approx. 6" (15cm) between fixture and other devices or a wall for proper cooling

brighter

ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

- Always disconnect fixture from main power source before performing any type of service or cleaning procedure
- Only handle the power cord by the plug end. Never pull out the plug by tugging the wire portion of the cord
- During the initial operation of this fixture, a light smoke or smell may emit from the interior of the fixture. This is a
 normal process and is caused by excess paint in the interior of the casing burning off from the heat associated
 with the lamp and will decrease gradually over time.
- Consistent operational breaks will ensure fixture will function properly for many years.
- ONLY use the original packaging and materials to transport the fixture in for service.

2. MAINTENANCE GUIDELINES

DISCONNECT POWER BEFORE PERFORMING ANY MAINTENANCE!

2.1. CLEANING

Frequent cleaning is recommended to ensure proper function, optimized light output, and an extended life. The frequency of cleaning depends on the environment in which the fixture operates: damp, smoky or particularly dirty environments can cause greater accumulation of dirt on the fixture's optics. Periodically clean the external lens surface with a soft cloth to avoid dirt/debris accumulation. NEVER use alcohol, solvents, or ammonia-based cleaners.

2.2. MAINTENANCE

Regular inspections are recommended to ensure proper function and extended life. There are no user serviceable parts inside this fixture. Please refer all other service issues to an authorized our service technician. Should you need any spare parts, please order genuine parts from your local dealer.

Please refer to the following points during routine inspections:

- A detailed electric check by an approved electrical engineer every three months, to make sure the circuit contacts are in good condition and prevent overheating
- Be sure all screws and fasteners are securely tightened at all times. Loose screws may fall out during normal operation, resulting in damage or injury as larger parts could fall
- Check for any deformations on the housing, color lenses, rigging hardware, and rigging points (ceiling, suspension, trussing). Deformations in the housing could allow for dust to enter into the fixture. Damaged rigging points or unsecured rigging could cause the fixture to fall and seriously injure a person(s)

brighter

ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

• Electric power supply cables must not show any damage, material fatigue or sediments. NEVER remove the ground prong from the power cable

3.DMX CHART

6CH Mode

СН	Value	Percent	Function
1CH	0-255	0%-100%	Red
2CH	0-255	0%-100%	Green
3CH	0-255	0%-100%	Blue
4CH	0-255	0%-100%	Cyan
5CH	0-255	0%-100%	Lime
6CH	0-255	0%-100%	Amber

12CH Mode

СН	Value	Percent	Function
1CH	0-255	0%-100%	Red
2CH	0-255	0%-100%	Green
3CH	0-255	0%-100%	Blue
4CH	0-255	0%-100%	Cyan
5CH	0-255	0%-100%	Lime
6CH	0-255	0%-100%	Amber
7CH	0-255	0%-100%	Master Dimmer
8CH	0-255	0%-100%	Strobe
	0	0%-0,4%	Open
	1-255	0,5%-100%	Strobe S>F
9CH	0-255	0%-100%	Zoom (Narrow to Wide)
10CH	0-255	0%-100%	CTO (Cold to Warm)
11CH	0-5	0%-2,3%	Off
	6-127	2,4%-50%	3200K
	128-255	51%-100%	Flame
12CH	0-255	0%-100%	Color Macro



ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

4.SPECIFICATIONS

CONSTRUCTION/PHYSICAL

Dimensions: 520x315x320mm

Weight: 8,4 Kg

Exterior Color: Black

DYNAMIC EFFECTS

Dimmer: Electronic

Shutter/Strobe: Electronic

Strobe Rate: 0-25Hz

Standalone: Yes

Color Mixing: RGBALC

CONNECTIONS

Power Connection: PowerCon DMX Connection: XLR 3-pin or 5-pin

CONTROL

Control Protocols: DMX DMX Channels: 6/12 CH Build-in Effects: Yes

ELECTRICAL

Power Supply Voltage: 100-240V 50/60Hz Maximum Power Consumption: 350W Light Source: 400W RGBALC COB LED

OPTIC


Zoom: 15°-55°







ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

5.DIMENSIONAL DRAWINGS







Page 6 of 7





ul. Warszawska 111 32-087 Bibice POLAND NIP: 9442248196 REGON: 361197164

brighter

BRIGHTER LIGHTING SP. Z.O.O.

ul. Warszawska 111 32-087 Bibice POLAND

NIP: 9442248196

REGON: 361197164

The manufacturer reserves the right to make changes to technical parameters